









PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE.
Always swab self-sealing port with sterile alcohol prior to accessing with a sterile syringe.

<p>Step 1:</p>  <p>Using the filter needle, draw up 6mL of Citrate Anticoagulant into the 60mL syringe.</p>	<p>Step 2:</p>  <p>Draw 54mL whole blood from the patient, filling the syringe to 30mL.</p>	<p>Step 3:</p>  <p>Remove the red cap and slowly load the 60mL of anticoagulated whole blood into the Concentrating Device.</p>
<p>Step 4:</p>  <ol style="list-style-type: none"> Place the Concentrating Device and Counterbalance Device* in the centrifuge buckets at opposite ends. Process at: <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Executive Series Centrifuge 7 minutes - 4400 RPM</p> <p>Platinum/Sapphire Series Centrifuge AbsolutePRP/BMC</p> </div> <p>*Counterbalance Device needs to be filled with water weighing equal to the Concentrating Device (+/- 3g).</p>	<p>Step 5:</p>  <p>RBC interface reaches 7mL volume marker</p> <p>Attach the 60mL syringe and aspirate the plasma until the RBC interface reaches the 7mL volume marker, then stop aspirating.</p>	<p>Step 6:</p>  <p>7mL PRP (Plasma & Platelet buffycoat)</p> <p>Attach the 12mL syringe and aspirate 7mL of PRP. Gently agitate the syringe to re-suspend the platelet buffycoat into the plasma.</p>

If you have any questions, please reach out to our Clinical Education Team:
education@plymouthmedical.com or 888.392.5076 Ext. 3